

SET OF ELECTRIC

SALT & PEPPER MILLS

User manual SET OF ELECTRIC SALT & PEPPER MILLS

Návod k obsluze SADA ELEKTRICKÝCH MLÝNKŮ NA SŮL A PEPŘ

Návod na obsluhu SÚPRAVA ELEKTRICKÝCH MLYNČEKOV NA SOĽ A ČIERNE KORENIE

Használati útmutató ELEKTROMOS SÓ- ÉS BORS-DARÁLÓ SZETT



SET OF ELECTRIC SALT & PEPPER MILL

SADA ELEKTRICKÝCH MLÝNKŮ NA SŮL A PEPŘ

SÚPRAVA ELEKTRICKÝCH MLYNČEKOV NA SOĽ A ČIERNE KORENIE


ELEKTROMOS SÓ- ÉS BORS-DARÁLÓ SZETT

CATLER RECOMMENDS SAFETY FIRST

We at Catler are very safety conscious. We design and manufacture consumer products with the safety of you, our valued customer foremost in mind. In addition we ask that you exercise a degree of care when using any electrical appliance and adhere to the following precautions:

- Children should be supervised to ensure that they will not play with the appliance.
- Read all instructions before putting the mills into operation and save them for future reference.
- · Remove any promotional labels / stickers before using the mills.
- Do not place the mills on or near a hot gas or electric burner or where it could touch a heated oven. Do not expose the mills to direct sunlight.
- Before first use, check that you have correctly inserted 6 x AAA alkaline batteries (LR03).
 Do not use the mills if they are not assembled properly.
- Replace flat batteries with new ones. Do not combine new and used batteries.
- · If you do not use the mills for a longer time, always remove the batteries.
- Dispose of fl at batteries in accordance with local regulations. Do not throw batteries into standard household waste, but take to a location designated for battery disposal.
- Keep the salt and pepper mills clean. More information found in chapter "Cleaning electric mills".
- Do not use abrasive cleaning products or steel wool so that you do not scratch the surface.
- · Salt and pepper mills are designed only for household use.
- Any maintenance other than standard cleaning should be carried out exclusively by an authorised service centre.

DESCRIPTION OF ELECTRIC MILLS



 Dial is located on the base of the mill. For a coarse grinding, turn the dial anti-clockwise, for a fine grinding, turn the dial clockwise

OPERATION

Remove and safely discard any packaging material or promotional labels before using the electric mills for the first time. Wipe your electric mills over with a soft, damp cloth and dry thoroughly.

Inserting batteries

To insert the batteries, grasp the stainless steel shaft with one hand. Using the other hand, turn the compartment anti-clockwise and remove the shaft.

Insert 6 x AAA alkaline batteries (LR03) according to polarity graphics in battery compartment.

Replace the shaft and turn clockwise to the position. Ensure the mill is correctly assembled, you will hear a click.

If you do not use the mill for a longer time, always remove the batteries.

NOTE

Filling compartment

The electric mills are intended for grinding crystal salt and pepper.

Before using salt, please refer to salt manufacturer whether its salt is suitable for grinding in electric mill. Some varieties of salt (for example rock salt) are not suitable for grinding in a mill.

To fill the compartment, grasp the stainless steel shaft with one hand. Using the other hand, turn the compartment anti-clockwise. Remove the shaft. Then remove the motor with inserted batteries. Fill the compartment with crystal salt or pepper to ¾ of total compartment capacity. Assemble the mill the opposite way you disassemble the mill.

Operation of mills

To operate the mill, press the operating button. Untill you loosen the operation button, the grinding process will continue.

Adjusting the grind

Electric mills allow you to adjust a coarseness of grind. The coarseness of grind can be set from coarse to fine grinding according to the meals you wish to season. For a coarse grind, turn the dial at the bottom of the mill anticlockwise. For a fine grind, turn the dial at the bottom of the mill clockwise.

Cleaning electric mills

To clean the mill shaft, wipe the outside with a damp soft cloth and dry thoroughly. Do not use steel wool, scouring pads or abrasive kitchen cleaners as they will scratch the mills.

To clean the inside of the salt/pepper compartment, at first remove any excess salt/pepper. Clean the inside with a dry brush with soft hair. Be careful when cleaning grinding blades. These are sharp and risk of hurt.

Never immerse the electric mills in water or any other liquid. Do not place mills or any its part in the dishwasher.

NOTE

Storing mills

Store mills in a dry and cool location, like a kitchen cupboard. This will help prevent the salt from higher temperatures and humidity. If you do not use the mills for a longer time, always remove all batteries.

INSTRUCTIONS AND INFORMATION REGARDING THE DISPOSAL OF USED PACKAGING MATERIALS

Dispose of packaging material at a public waste disposal site.

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC APPLIANCES



The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this product at your applicable collection point for the recycling of electrical & electronic equipment waste. Alternatively in some states of the European Union or other European states you may return your products to your local retailer when buying an equivalent new product. The correct disposal of this product will help save valuable natural resources and help in preventing the potential negative impact on the environment and human health, which could be caused as a result of improper liquidation of waste. Please ask your local authorities or the nearest waste collection centre for further details. The improper disposal of this type of waste may fall subject to national regulations for fines

For business entities in the European Union

If you wish to dispose of an electrical or electronic device, request the necessary information from your seller or supplier.


Disposal in other countries outside the European Union

If you wish to dispose of this product, request the necessary information about the correct disposal method from local government departments or from your seller.

DISPOSAL OF USED BATTERIES

Do not place used batteries in standard household waste. Take them to designated collection points. More information is available at local government authorities.

Right to amend the text and technical specifications reserved.





SET OF ELECTRIC

SALT & PEPPER MILLS

Due to continual improvements in design or otherwise, the product you purchase may differ slightly from the one illustrated in this booklet.

Z důvodu neustálého zdokonalování designu a dalších vlastností se může vámi zakoupený výrobek mírně lišit od výrobku uvedeného na obrázcích v tomto návodu.

Z dôvodu neustáleho zdokonaľovania dizajnu a ďalších vlastností sa môže vami zakúpený výrobok mierne líšiť od výrobku uvedeného na obrázkoch v tomto návode.

A kivitel és más jellemzők folytonos fejlesztése miatt az Ön által megyásárolt termék kissé eltérhet e útmutató képein ábrázolt terméktől



W W W . C A T L E R . E U